

CHEST PRESS (PL-PV2-CP)




POWER LEVERAGE V2

INSTALLATION MANUAL

CHEST PRESS (PL-PV2-CP)

No.	Name	Unit	Qty.
1	column component	pcs	1
2	seat component	pcs	1
3	plate rotating arm component	pcs	1
4	right frame component	pcs	1
5	left frame component	pcs	1
6	plate rotating arm component	pcs	1
7	right-hand rotating arm component	pcs	1
8	front lower beam component	pcs	1
9	left-hand rotating arm component	pcs	1
10	adjustment tube component	pcs	2
11	front protective plate	pcs	1
12	m10*20 flat round head screw	pcs	4



INSTALLATION MANUAL