

# HEAVY DUTY DIP (PL-PV2-DP2)




# POWER LEVERAGE V2

## INSTALLATION MANUAL

# HEAVY DUTY DIP (PL-PV2-DP2)



| No. | Name                        | Unit | Qty. |
|-----|-----------------------------|------|------|
| 1   | vertical column component 1 | pcs  | 1    |
| 2   | vertical column component 2 | pcs  | 1    |
| 3   | pivot arm component 1       | pcs  | 1    |
| 4   | pivot arm component 2       | pcs  | 1    |
| 5   | seating component           | pcs  | 1    |
| 6   | base connector component    | pcs  | 1    |
| 7   | connector component         | pcs  | 1    |



## INSTALLATION MANUAL

POWER  
LEVERAGE **V2**